







































Original	Replacement	Original	Replacement
	Power		Sleep / Timer
	Mute		AV / Input / RDS
	1		CH+ / Page+
	2		Vol+
	3		Info / Angle
	4		CH- / Page-
	5		Vol-
	6		Shift + Menu /
	7		Fav / Marker / PC
	8		Setup / OPT /
	9		Smart / List
	TV / Radio		Up
	0		Left
	Recall / Mouse		OK
	Picture / Format		Right
	Sound / Title		Menu / Home
	Audio / Lang I/II		Down





Original	Replacement
 Exit	 Exit / Cancel / Clear
 I<< / Text	 Text / Goto
 I<< / Text	 I<< / Preset-
 >>I / Subpage	 >>I / Preset+
 << / Size	 << / Tune-
 >> / Reveal	 >> / Tune+
 Play/Pause / Index	 Play / Slow
 Stop / Hold	 Stop / Hold
 Cancel	 Shift + Exit / Cancel / Clear
 Subtitle	 Subtitle / EQ
 Repeat	 Shift + Green / APP /
 Freeze	 Pause / Step / Freeze
 A - B	 Shift + Yellow / YouTube /
 Media	 Display / Media
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat

Original	Replacement
 Blue	 Blue / Prime Video / Random

