



Original	Replacement
	Power
	Eject / Surround
	9
	3
	AV / Input / RDS
	Up
	Down
	>>I / Preset+
	I<< / Preset-
	OK
	Vol+
	Vol-
	Mute / Dimmer
	Play / Slow
	Menu / Home
	Display / Media
	Green / APP / Repeat

Original	Replacement
	TV/Radio /
	Sound / Title
	Sleep / Timer
	Setup / OPT /

