





Original	Replacement	Original	Replacement
	Power		Power
	Source		AV / Input / RDS
	Vol+		Vol+
	Vol-		Vol-
	Mute		Mute / Dimmer
	Back		Back / Return
	I<<		I<< / Preset-
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	>>I		>>I / Preset+
	Sound Effect		Smart / List
	Surr. Sound		Sound / Title
	Audio Sync		Audio / Lang I/II
	Woofer		Green / APP / Repeat
	Treble/Bass		Shift + Smart / List
	Dimmer/AnyNet		Display / Media

