

















































































































Original	Replacement	Original	Replacement
	Open/Close		Eject / Surround
	Mute		Mute / Dimmer
	DVD		Shift + 2
	Tuner		Shift + 6
	Scart		Yellow / YouTube / Repeat
	AUX		Shift + 7
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	+10		Shift + Guide / EPG / -/-
	Setup		Setup / OPT /
	FM Mode		Guide / EPG / -/-
	Pre/Tun		Fav / Marker / PC
	Memo		Rec / Rec Mode
	Auto		D.Menu / Top
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	Enter		OK
	Pause/Step		Pause / Step / Freeze
	Play		Play / Slow
	Stop		Stop / Hold
	Vol-		Vol-
	Vol+		Vol+
	CH-		CH- / Page-
	CH+		CH+ / Page+





Original	Replacement
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 <<	 << / Tune-
 >>	 >> / Tune+
 Zoom	 Zoom / Size
 Prog	 TV/Radio /
 Slow	 Shift + Play /
 A-B	 Shift + YouTube / YouTube /
 Goto	 Text / Goto
 Title	 Sound / Title
 Menu	 Menu / Home
 Display	 Display / Media
 Subtitle	 Subtitle / EQ
 N/P	 Shift + Setup / OPT / Tools
 Language	 Audio / Lang I/II
 Angle	 Info / Angle
 Resume	 Shift + Display / Media

Original	Replacement
 Repeat	 Green / APP / Repeat
 R/L	 Shift + Subtitle / EQ
 Video	 Shift + 4
 Return	 Back / Return

