







































































| Original  | Replacement     | Original  | Replacement           |
|---|-----------------|---|-----------------------|
|      | Power           |      | Power                 |
|      | Rec             |      | Rec / Rec Mode        |
|      | Pause           |      | Pause / Step / Freeze |
|      | Stop            |      | Stop / Hold           |
|      | <<              |      | << / Tune-            |
|      | Play            |      | Play / Slow           |
|      | >>              |      | >> / Tune+            |
|      | I<              |      | I<< / Preset-         |
|      | >I              |      | >>I / Preset+         |
|     | Back            |     | Back / Return         |
|    | Start (Windows) |    | Smart / List          |
|    | i More          |    | Info / Angle          |
|    | Up              |    | Up                    |
|    | Left            |    | Left                  |
|    | OK              |    | OK                    |
|    | Right           |    | Right                 |
|    | Down            |    | Down                  |
|    | Volume+         |    | Vol+                  |
|    | Mute            |    | Mute / Dimmer         |
|    | CH/PG+          |    | CH- / Page-           |
|    | Volume-         |    | Vol-                  |
|    | CH/PG-          |    | CH+ / Page+           |
|    | Recorded TV     |    | Display / Media       |
|    | Guide           |    | Guide / EPG / -/-     |
|    | Live TV         |    | TV/Radio /            |
|    | Format / DVD    |    | D.Menu / Top          |
|   | 1               |   | 1                     |
|  | 2               |  | 2                     |
|  | 3               |  | 3                     |
|  | 4               |  | 4                     |
|  | 5               |  | 5                     |
|  | 6               |  | 6                     |
|  | 7               |  | 7                     |
|  | 8               |  | 8                     |





| Original    |              | Replacement |                             |
|-------------|--------------|-------------|-----------------------------|
|             | 9            |             | 9                           |
|             | *            |             | Shift + Guide / EPG / -/-   |
|             | 0            |             | 0                           |
| # button"/> | #            |             | Shift + Fav / Marker / PC   |
|             | Clear        |             | Exit / Cancel / Clear       |
|             | [T] Teletext |             | Text / Goto                 |
|             | Enter        |             | Fav / Marker / PC           |
|             | Red          |             | Red / Netflix / Search      |
|             | Green        |             | Green / APP / Repeat        |
|             | Yellow       |             | Yellow / YouTube / Repeat   |
|             | Blue         |             | Blue / Prime Video / Random |
|             |              |             |                             |
|             |              |             |                             |
|             |              |             |                             |
|             |              |             |                             |
|             |              |             |                             |
|             |              |             |                             |
|             |              |             |                             |
|             |              |             |                             |

| Original |  | Replacement |  |
|----------|--|-------------|--|
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |
|          |  |             |  |

