







































































Original	Replacement	Original	Replacement
 Power	 Power	 Recall	 Smart / List
 Mute	 Mute / Dimmer	 Sub.PG	 Display / Media
 1	 1	 Down.PG	 CH- / Page-
 2	 2	 Up/CH+	 Up
 3	 3	 Vol-	 Vol-
 4	 4	 Left	 Left
 5	 5	 Enter	 OK
 6	 6	 Vol+	 Vol+
 7	 7	 Right	 Right
 8	 8	 Scan	 Setup / OPT /
 9	 9	 Down/CH-	 Down
 -/--	 Guide / EPG / -/--	 Tv/AV	 AV / Input / RDS
 0	 0	 Play	 Play / Slow
 Recall	 Back / Return	 Pause	 Pause / Step / Freeze
 Size Aspect	 Zoom / Size	 Stop/DVB-Menu	 Stop / Hold
 Index	 Info / Angle	 Exit/Eject	 Exit / Cancel / Clear
 Up.PG	 CH+ / Page+	 Sleep/USB-C.R.	 Sleep / Timer





Original	Replacement	Original	Replacement
  <</Info	  << / Preset-		
 Tv/Radio Setup	 TV/Radio /		
 ↑ H+	 Shift + Up		
 Subtitle	 Subtitle / EQ		
 >> /Guide	 >>  / Preset+		
 ← V-	 Shift + Left		
 Menu Enter	 Menu / Home		
 → V+	 Shift + Right		
 <</FAV	 << / Tune-		
 Language/Display	 Audio / Lang I/II		
 ↓ H-	 Shift + Down		
 TTX Search	 Text / Goto		
 Red	 Red / Netflix / Search		
 >>	 >> / Tune+		
 Green/Menu	 Green / APP / Repeat		
 Yellow/Audio	 Yellow / YouTube / Repeat		
 Blue/Title	 Blue / Prime Video / Random		

