




































| Original | Replacement |
|--|---|
|  Mute |  Mute / Dimmer |
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  16:9 |  Picture / Format |
|  0/FAV |  Fav / Marker / PC |
|  0/FAV |  0 |
|  [O]/Repeat |  Shift + Green / APP / |
|  Vol+ |  Vol+ |
|  Input |  AV / Input / RDS |

| Original | Replacement |
|--|--|
|  P+ |  CH+ / Page+ |
|  Vol- |  Vol- |
|  EPG/?/A-B |  Shift + Yellow / YouTube / |
|  EPG/?/A-B |  Guide / EPG / -/-- |
|  P- |  CH- / Page- |
|  Up |  Up |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Down |  Down |
|  Q/Double |  Shift + Red / Netflix / |
|  M |  Menu / Home |
|  ← |  Back / Return |
|  i |  Info / Angle |
|  Red |  Red / Netflix / Search |
|  Play/Pause |  Play / Slow |
|  Green |  Green / APP / Repeat |



