









































































Original	Replacement	Original	Replacement
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
App	 Media	Exit	 Exit
Info	 Info	Menu Down	 Down
Epg	 +  Shift + Guide	Back	 Back
Opt?	 Options	Volume+	 Vol +
Video	 Smart	CH/Page+	 Ch +
Subt.List	 Subt	Volume-	 Vol -
Sleep Timer	 Sleep	Audio	 Dual
TV	 TV/R	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Menu Left	 Left	6mno	 6
Display	 +  Shift + Info	7pqrm	 7



Original	Replacement	Original	Replacement
8tuv	 8		 +  Shift + Ch -
9wxyz	 9	Alt/16:9	 Format
Guide Pilote	 Guide	H/V Play	 Play
0/10	 0	Dec/Pause	 Pause
FAV Pref.	 Pre Ch		
East	 +  Shift + Right		
Red	 Red		
Green	 Green		
Dev	 D. Menu		
Yellow	 Yellow		
West	 +  Shift + Left		
Freeze	 +  Shift + Pause		
Blue	 Blue		
Lang./Rewind	 <<		
Lang./Rewind	 +  Shift + Dual		
	 +  Shift + Ch +		
LNB F.Forward	 >>		





































Original	Replacement	Original	Replacement
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Opt?	 Options	Menu Down	 Down
Subt.List	 Subt	Audio	 Dual
Video	 Smart	Back	 Back
App	 Media	Volume+	 Vol +
Info	 Info	CH/Page+	 Ch +
Zoom	 Eject	Volume-	 Vol -
Sleep Timer	 Sleep	CH/Page-	 Ch -
TV	 TV/R	1. ?	 1
Display	 +  Shift + Info	2abc	 2
Text	 Text	3def	 3
TV/SAT	 AV	4ghi	 4
Menu	 Menu	5jkl	 5
Menu Up	 Up	6mno	 6
Menu Left	 Left	7pqrm	 7




Original	Replacement	Original	Replacement
8tuv	 8	Freeze	 Pause
9wxyz	 9	Blue	 Blue
Guide Pilote	 Guide		 Shift + Mute
0/10	 0	Store	 Shift + Down
FAV Pref.	 Pre Ch		
Navi Mode	 List		
East	 Shift + Right		
Red	 Red		
+	 Shift + Ch +		
Lang./Rewind	 <<		
Lang./Rewind	 Shift + Dual		
Scan/Setup	 Shift + Options		
Alt/16:9	 Format		
Green	 Green		
West	 Shift + Left		
Dev	 D. Menu		
Yellow	 Yellow		



Original	Replacement	Original	Replacement
PWR On/Off	 Power	Audio	 Dual
Mute	 Mute	CH/Page-	 Ch -
Subt.List	 Subt	1. ?	 1
Sleep Timer	 Sleep	2abc	 2
TV	 TV/R	3def	 3
Video	 Smart	4ghi	 4
TV/SAT	 AV	5jkl	 5
Menu	 Menu	6mno	 6
Menu Up	 Up	7pqrm	 7
Display	 Info	8tuv	 8
Menu Left	 Left	9wxyz	 9
Menu Right	 Right	Guide Pilote	 Guide
Exit	 Exit	0/10	 0
Menu Down	 Down	FAV Pref.	 Pre Ch
Volume+	 Vol +	Red	 Red
CH/Page+	 Ch +	Green	 Green
Volume-	 Vol -	Yellow	 Yellow



Original	Replacement	Original	Replacement
Blue	 Blue		
On/Off	 +  Shift + Power		
West	 +  Shift + Left		
Dev	 D. Menu		
East	 +  Shift + Right		
	 +  Shift + Ch +		
	 +  Shift + Ch -		
Freeze	 +  Shift + Pause		
Lang./Rewind	 +  Shift + Dual		
Lang./Rewind	 <<		
H/V Play	 Play		
Dec/Pause	 Pause		
LNB F.Forward	 >>		

