








































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 FAV	 Pre Ch
 Recall	 Back
 Audio	 Dual
 Subtitle	 Subt
 Info	 Info

Original	Replacement
 Menu	 Menu
 EPG	 Guide
 Exit	 Exit
 Up	 Up
 CH+	 Ch +
 Down	 Down
 CH-	 Ch -
 Right	 Right
 Vol+	 Vol +
 Left	 Left
 Vol-	 Vol -
 OK	 Ok
 Text	 Text
 Red	 Red
 Green	 Green
 Pause	 Pause
 Yellow	 Yellow



