


































































Original	Replacement
 Open/Close	 Eject / Surround
 Mute	 Mute / Dimmer
 P/I	 Exit / Cancel / Clear
 Setup	 Setup / OPT /
 Angle	 Info / Angle
 Random	 Blue / Prime Video / Random
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Guide / EPG / -/-

Original	Replacement
 Language	 Audio / Lang I/II
 Display	 Display / Media
 Title	 Sound / Title
 Menu	 Menu / Home
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Search	 Red / Netflix / Search
 Repeat	 Green / APP / Repeat
 A-B	 Yellow / YouTube / Repeat
 Zoom	 Zoom / Size
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Play	 Play / Slow
 Vol+	 Vol+



