



| Original  | Replacement | Original  | Replacement       |
|---|-------------|---|-------------------|
|    | Mute        |    | Mute / Dimmer     |
|    | ATV/DTV     |    | Eject / Surround  |
|    | Power       |    | Power             |
|    | 1           |    | 1                 |
|    | 2           |    | 2                 |
|    | 3           |    | 3                 |
|    | CH+         |    | CH+ / Page+       |
|    | 4           |    | 4                 |
|    | 5           |    | 5                 |
|    | 6           |    | 6                 |
|    | CH-         |    | CH- / Page-       |
|  | 7           |  | 7                 |
|  | 8           |  | 8                 |
|  | 9           |  | 9                 |
|  | Vol+        |  | Vol+              |
|  | Guide       |  | Guide / EPG / -/- |
|  | 0           |  | 0                 |

| Original  | Replacement  | Original  | Replacement           |
|---|--------------|---|-----------------------|
|    | Sleep        |    | Sleep / Timer         |
|    | Vol-         |    | Vol-                  |
|    | Text         |    | Text / Goto           |
|    | Text Subpage |    | Setup / OPT /         |
|    | CH. List     |    | Smart / List          |
|    | Subtitle     |    | Subtitle / EQ         |
|    | I-II         |    | Audio / Lang I/II     |
|    | P.Size       |    | Zoom / Size           |
|    | P.Mode       |    | Picture / Format      |
|    | Exit         |    | Exit / Cancel / Clear |
|    | Up           |    | Up                    |
|  | Menu         |  | Menu / Home           |
|  | Left         |  | Left                  |
|  | OK           |  | OK                    |
|  | Right        |  | Right                 |
|  | Info         |  | Info / Angle          |
|  | Down         |  | Down                  |





| Original |             | Replacement |                             | Original | Replacement |
|----------|-------------|-------------|-----------------------------|----------|-------------|
|          | Source      |             | AV / Input / RDS            |          |             |
|          | Text Index  |             | Shift + Text /              |          |             |
|          | Text Reveal |             | D.Menu / Top                |          |             |
|          | Text Size   |             | Shift + Zoom /              |          |             |
|          | Text Hold   |             | Pause / Step / Freeze       |          |             |
|          | Red         |             | Red / Netflix / Search      |          |             |
|          | Green       |             | Green / APP / Repeat        |          |             |
|          | Yellow      |             | Yellow / YouTube / Repeat   |          |             |
|          | Blue        |             | Blue / Prime Video / Random |          |             |
|          |             |             |                             |          |             |
|          |             |             |                             |          |             |
|          |             |             |                             |          |             |
|          |             |             |                             |          |             |
|          |             |             |                             |          |             |
|          |             |             |                             |          |             |
|          |             |             |                             |          |             |
|          |             |             |                             |          |             |
|          |             |             |                             |          |             |
|          |             |             |                             |          |             |
|          |             |             |                             |          |             |
|          |             |             |                             |          |             |

