




































| Original | Replacement |
|--|---|
|  Power |  Power |
|  Mute |  Mute / Dimmer |
|  PIP- |  Shift + CH- / |
|  PIP |  Zoom / Size |
|  PIP+ |  Shift + CH+ / |
|  Wide |  Picture / Format |
|  Swap |  Smart / List |
|  Lang(AD) |  Audio / Lang I/II |
|  Timers |  Sleep / Timer |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |

| Original | Replacement |
|--|---|
|  9 |  9 |
|  Text |  Text / Goto |
|  0 |  0 |
|  AV |  AV / Input / RDS |
|  i |  Info / Angle |
|  Vol+ |  Vol+ |
|  Tv/Radio |  TV/Radio / |
|  PR+ |  CH+ / Page+ |
|  Vol- |  Vol- |
|  FAV |  Fav / Marker / PC |
|  PR- |  CH- / Page- |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  Guide |  Guide / EPG / -/- |
|  Up |  Up |





| Original | | Replacement | | Original | | Replacement | |
|---|----------|---|-----------------------|----------|--|-------------|--|
|  | Exit |  | Exit / Cancel / Clear | | | | |
|  | Left |  | Left | | | | |
|  | OK |  | OK | | | | |
|  | Right |  | Right | | | | |
|  | Menu |  | Menu / Home | | | | |
|  | Down |  | Down | | | | |
|  | Back/P<P |  | Back / Return | | | | |
|  | Subtitle |  | Subtitle / EQ | | | | |
|  | << |  | << / Tune- | | | | |
|  | Play |  | Play / Slow | | | | |
|  | >> |  | >> / Tune+ | | | | |
|  | LIB |  | Setup / OPT / | | | | |
|  | Stop |  | Stop / Hold | | | | |
|  | Pause |  | Pause / Step / Freeze | | | | |
|  | Rec |  | Rec / Rec Mode | | | | |
| | | | | | | | |
| | | | | | | | |

