



Original	Replacement
	Power
	Mode
	Mute / Dimmer
	Band
	Vol+
	APS
	I<< / Preset-
	Sel
	>>I / Preset+
	CLK
	Vol-
	ST
	1/PAU
	2/INT
	3/RPT
	4/RDM
	5/↓

Original	Replacement
	6/↑
	7/*
	8/0
	9/#

