
















Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Tv/Sat	 AV
 Tv/Radio	 TV/R
 Language	 Dual
 Audio	 Shift + Dual
 Mute	 Mute
 Info	 Info

Original	Replacement
 A	 Shift + Red
 B	 Shift + Green
 Freeze	 Pause
 Red / Tri	 Red
 Green / Guide	 Guide
 Green / Guide	 Green
 Yellow / Retour	 Yellow
 Yellow / Retour	 Back
 Blue / Menu	 Blue
 Blue / Menu	 Menu
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 Ok	 Ok
 Fav 1	 Shift + 1
 Fav 2	 Shift + 2





	Original	Replacement	
	Fav 3	SHIFT + 3	Shift + 3
	Fav 4	SHIFT + 4	Shift + 4
	Fav 5	SHIFT + 5	Shift + 5
	Fav 6	SHIFT + 6	Shift + 6
	Fav 7	SHIFT + 7	Shift + 7
	Fav 8	SHIFT + 8	Shift + 8
	Page+	+ CH	Ch +
	Page -	CH -	Ch -
	Fly Link	HOME SMART	Smart
	Sat-Messenger	APP MEDIA	Media
	Vol +	+ VOL	Vol +
	Vol -	VOL -	Vol -

	Original	Replacement

