






































































Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 Stereo	 Sound / Title
 Format D'Image	 Picture / Format
 Mode Image	 Zoom / Size
 Mode Audio	 Audio / Lang I/II
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 --	 Shift + Guide / EPG / --
 0	 0

Original	Replacement
 Recall / Rep	 Fav / Marker / PC
 Info	 Info / Angle
 Gel Image	 Smart / List
 Rec/Auto	 Rec / Rec Mode
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Up	 Up
 Source	 AV / Input / RDS
 Arrêt Prog	 Exit / Cancel / Clear
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Menu	 Menu / Home
 CH+	 CH+ / Page+



