


































































| Original | | Replacement | | Original | | Replacement | |
|-------------------------------------------------------------------------------------|--------|-------------------------------------------------------------------------------------|--------------------|---------------------------------------------------------------------------------------|-------------|---------------------------------------------------------------------------------------|----------------------------|
|  | Power |  | Power |  | Vol- |  | Vol- |
|  | Mute |  | Mute / Dimmer |  | Home |  | Menu / Home |
|  | 1 |  | 1 |  | P- |  | CH- / Page- |
|  | 2 |  | 2 |  | * |  | Smart / List |
|  | 3 |  | 3 |  | Up |  | Up |
|  | 4 |  | 4 |  | i |  | Info / Angle |
|  | 5 |  | 5 |  | Left |  | Left |
|  | 6 |  | 6 |  | OK |  | OK |
|  | 7 |  | 7 |  | Right |  | Right |
|  | 8 |  | 8 |  | Back |  | Back / Return |
|  | 9 |  | 9 |  | Down |  | Down |
|  | EPG |  | Guide / EPG / -/-- |  | Exit |  | Exit / Cancel / Clear |
|  | 0 |  | 0 |  | Netflix |  | Shift + Red / Netflix / |
|  | TXT |  | Text / Goto |  | YouTube |  | Shift + Yellow / YouTube / |
|  | Vol+ |  | Vol+ |  | prime video |  | Shift + Blue / Prime |
|  | Source |  | AV / Input / RDS |  | USB |  | Shift + 8 |
|  | P+ |  | CH+ / Page+ |  | Red |  | Red / Netflix / Search |





| Original | Replacement | Original | Replacement |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|----------|-------------|
|  | Green  Green / APP / Repeat | | |
|  | Yellow  Yellow / YouTube / Repeat | | |
|  | Blue  Blue / Prime Video / Random | | |
|  | <<  << / Tune- | | |
|  | Play  Play / Slow | | |
|  | Pause  Pause / Step / Freeze | | |
|  | >>  >> / Tune+ | | |
|  | Rec  Rec / Rec Mode | | |
|  | Stop  Stop / Hold | | |
|  | Audio  Audio / Lang I/II | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

