






































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	ATV/DTV		Guide / EPG / -/--
	Recall		Back / Return
	P.Mode		Picture / Format
	S.Mode		Sound / Title
	Sleep		Sleep / Timer
	MTS		D.Menu / Top
	Menu		Menu / Home
	Up		Up
	Source		AV / Input / RDS
	Left		Left
	Enter		OK
	Right		Right
	Exit		Exit / Cancel / Clear
	Down		Down
	Display		Display / Media
	Vol+		Vol+
	Rec		Rec / Rec Mode
	Rec List		Shift + Rec / Rec Mode
	CH+		CH+ / Page+
	Vol-		Vol-
	Tv/Radio		TV/Radio /
	FAV List		Smart / List





Original	Replacement
 CH-	 CH- / Page-
 Play/Time Shift	 Play / Slow
 Pause	 Pause / Step / Freeze
 <</Guide	 << / Tune-
 >>/Aspect	 >> / Tune+
 Freeze	 Shift + Pause / Step /
 Stop/Index	 Stop / Hold
 <</Cancel	 << / Preset-
 >> /Sub.PG	 >> / Preset+
 Subtitle	 Subtitle / EQ
 Reveal	 Setup / OPT /
 Size	 Zoom / Size
 Hold	 Shift + Stop /
 Text	 Text / Goto
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat

Original	Replacement
 Cyan	 Blue / Prime Video / Random

