






































































| Original | | Replacement | | Original | | Replacement | |
|---|--------------|---|--------------|---|--------------|---|----------------|
|  | Power |  | Power |  | 8 |  | 8 |
|  | Mute |  | Mute |  | 9 |  | 9 |
|  | Tv/DVB-T |  | Smart |  | 0 |  | 0 |
|  | []/Line |  | Media |  | -/-- |  | Shift + Guide |
|  | [+]/Display |  | Info |  | PRE |  | Pre Ch |
|  | [≡]/TXT |  | Text |  | Vol+ |  | Vol + |
|  | PIP On/Off |  | Shift + 3D |  | Vol- |  | Vol - |
|  | PIP Swap |  | Shift + Subt |  | Prog+ |  | Ch + |
|  | PIP Source |  | Shift + AV |  | Prog- |  | Ch - |
|  | PIP Sound |  | Shift + TV/R |  | MS |  | Back |
|  | 1 |  | 1 |  | [▼]/Still |  | AV |
|  | 2 |  | 2 |  | Timer/Sleep |  | Shift + Power |
|  | 3 |  | 3 |  | [II]/Tv Menu |  | Menu |
|  | 4 |  | 4 |  | -I/I-/P.STD |  | Shift + Format |
|  | 5 |  | 5 |  | -I/I-/S.STD |  | Shift + Dual |
|  | 6 |  | 6 |  | Up/P+ |  | Up |
|  | 7 |  | 7 |  | Down/P- |  | Down |





| Original | Replacement | Original | Replacement |
|--|--|---|--|
|  Right/Vol+ |  Right |  Blue/Menu |  Blue |
|  Left/Vol- |  Left |  Timer/repeat |  Shift + Text |
|  Enter |  Ok |  [≡i]/A-B |  Shift + Info |
|  [<>]/P.Size |  Format |  [/≡]/Audio |  Dual |
|  -IXI/Exit |  Exit |  [≡♦]/Subtitle |  Subt |
|  Open/Close |  Eject |  [≡?]/Goto |  Options |
|  Rec |  Rec |  [≡+]/Program/Me |  TV/R |
|  Stop |  Stop |  [<≡]/List/Angle |  Shift + Ch - |
|  Play |  Play |  [≡>]/Bookmark/O |  Shift + Ch + |
|  Pause |  Pause |  [≡o]/Zoom/EPG |  Guide |
|  <</< Slow |  << |  [≡X]/Cancel/i |  3D |
|  Slow >/>> |  >> | | |
|  I<</<I Step |  I<< | | |
|  Step I>/>>I |  >>I | | |
|  Red/Setup |  Red | | |
|  Green/Input |  Green | | |
|  Yellow/Title |  Yellow | | |

