











































































































Original		Replacement		Original		Replacement	
	Power		Power		Info		Info
	Tv Standby		Shift + Power		Vol+		Vol +
	Input Tv		Shift + AV		Vol-		Vol -
	Mute Tv		Shift + Mute		CH+		Ch +
	Vol+ Tv		Shift + Right		CH-		Ch -
	Vol- Tv		Shift + Left		Up		Up
	CH+ Tv		Shift + Ch +		Down		Down
	CH- Tv		Shift + Ch -		Left		Left
	TV		TV/R		Right		Right
	Aspect/Ratio		Format		OK		Ok
	HD		Smart		FAV		Pre Ch
	Mosaic		Media		Planner		Text
	Mute		Mute		Back		Back
	Messages		Options		Rec		Rec
	Help		AV		Pause		Pause
	Cancel		Shift + Back		Stop		Stop
	Guide		Guide		<<		<<





Original	Replacement	Original	Replacement
	Play		Play
	>>		>>
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	*		Dual
	#		Subt

