







































































Original	Replacement	Original	Replacement
	Power		Power
	16:9		Picture / Format
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Back		Back / Return
	Repeat		Shift + Green / APP /
	List Fav		Smart / List
	List Fav		Fav / Marker / PC
	Exit		Exit / Cancel / Clear
	Reveal / EPG		Guide / EPG / -/-
	Source		AV / Input / RDS
	Info		Info / Angle
	Menu		Menu / Home
	Red		Red / Netflix / Search
	Up		Up
	Yellow		Yellow / YouTube / Repeat
	Left		Left
	OK		OK
	Right		Right
	Green		Green / APP / Repeat
	Down		Down
	Blue		Blue / Prime Video / Random
	Vol+		Vol+
	P+		CH+ / Page+
	Vol-		Vol-





	Original	Replacement		Original	Replacement
	P-	CH- / Page-			
	TTX	Text / Goto			
	Rec	Rec / Rec Mode			
	T-Shift	Sleep / Timer			
	AD	Shift + Audio / Lang I/II			
	Index / Play/Pause	Play / Slow			
	Zoom / Stop	Zoom / Size			
	Zoom / Stop	Stop / Hold			
	Hold / I<<	Shift + Stop /			
	Hold / I<<	I<< / Preset-			
	Language / >>I	Sound / Title			
	Language / >>I	>>I / Preset+			
	Subtitle	Subtitle / EQ			
	Audio	Audio / Lang I/II			

