




































Original	Replacement
 Standby	 Power
 Mute	 Mute
 Display	 Shift + Info
 Sleep	 Sleep
 Aspect	 Format
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/+	 Shift + Guide
 Recall	 Back

Original	Replacement
 LCD-Menu	 Menu
 DVB-Menu	 D. Menu
 Up	 Up
 Left	 Left
 Enter	 Ok
 Right	 Right
 Down	 Down
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Source	 AV
 PMode	 Shift + Format
 SMode	 Shift + Dual
 Exit	 Exit
 Text	 Text
 Hold	 Stop





Original	Replacement	Original	Replacement
	PIP		3D
	Digest		Smart
	Red		Red
	Yellow		Yellow
	Green		Green
	Blue		Blue
	Size		Eject
	Reveal		List
	Subpage		Subt
	TV / Radio		TV/R
	Nicam		Options
	Lang		Dual
	Page-		Shift + Ch -
	Page+		Shift + Ch +
	EPG		Guide
	FAV		Pre Ch
	Index		Media
			Info
			Info

