





| Original | Replacement |
|--|--|
|  Mute |  Mute / Dimmer |
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  ✓ |  Guide / EPG / -/-- |
|  0 |  0 |
|  Red / <<< |  Red / Netflix / Search |
|  Red / <<< |  <<< / Tune- |
|  Green / Stop |  Green / APP / Repeat |
|  Green / Stop |  Stop / Hold |

| Original | Replacement |
|---|---|
|  Yellow / Play |  Play / Slow |
|  Yellow / Play |  Yellow / YouTube / Repeat |
|  Blue / >>> |  >>> / Tune+ |
|  Blue / >>> |  Blue / Prime Video / Random |
|  Up |  Up |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Down |  Down |
|  SFI |  D.Menu / Top |
|  Exit / Recall |  Back / Return |
|  Exit / Recall |  Exit / Cancel / Clear |
|  Info |  Info / Angle |
|  Prog + |  CH+ / Page+ |
|  TV / Radio |  TV/Radio / |
|  Vol + |  Vol+ |
|  Prog - |  CH- / Page- |





| Original | | Replacement | | Original | | Replacement | |
|---|-----------|---|-----------------------|----------|--|-------------|--|
|  | Menu |  | Menu / Home | | | | |
|  | Vol - |  | Vol- | | | | |
|  | TV/SAT |  | Smart / List | | | | |
|  | TXT |  | Text / Goto | | | | |
|  | Stop |  | Pause / Step / Freeze | | | | |
|  | EXT |  | Display / Media | | | | |
|  | SAT1 + OK |  | Shift + 2 | | | | |
|  | SAT2 + OK |  | Shift + 3 | | | | |
|  | TV + OK |  | Shift + 1 | | | | |
| | PIP |  | Picture / Format | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |





| Original | Replacement | | |
|----------|--------------|--|----------------------------|
| | Mute | | Mute / Dimmer |
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ✓ | | Guide / EPG / -/-- |
| | 0 | | 0 |
| | A/B | | Shift + Yellow / YouTube / |
| | Red / <<< | | <<< / Tune- |
| | Red / <<< | | Red / Netflix / Search |
| | Green / Stop | | Green / APP / Repeat |

| Original | Replacement | | |
|----------|---------------|--|-----------------------------|
| | Green / Stop | | Stop / Hold |
| | Yellow / Play | | Play / Slow |
| | Yellow / Play | | Yellow / YouTube / Repeat |
| | Blue / >>> | | >>> / Tune+ |
| | Blue / >>> | | Blue / Prime Video / Random |
| | Up | | Up |
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | Down | | Down |
| | SFI | | D.Menu / Top |
| | Exit / Recall | | Exit / Cancel / Clear |
| | Exit / Recall | | Back / Return |
| | Info | | Info / Angle |
| | Prog + | | CH+ / Page+ |
| | TV / Radio | | TV/Radio / |
| | Vol + | | Vol+ |





| Original | Replacement | Original | Replacement |
|----------|-------------|----------|-----------------------|
| | Prog - | | CH- / Page- |
| | Menu | | Menu / Home |
| | Vol - | | Vol- |
| | TV/SAT | | Smart / List |
| | TXT | | Text / Goto |
| | Stop | | Pause / Step / Freeze |
| | EXT | | Display / Media |
| | SAT1 + OK | | Shift + 2 |
| | SAT2 + OK | | Shift + 3 |
| | TV + OK | | Shift + 1 |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Replacement | Original | Replacement |
|----------|-------------|----------|-------------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |





| Original | Replacement |
|--|---|
|  Mute |  Mute / Dimmer |
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  ✓ |  Guide / EPG / -/-- |
|  0 |  0 |
|  A/B |  Shift + Yellow / YouTube / |
|  Red / <<< |  Red / Netflix / Search |
|  Red / <<< |  <<< / Tune- |
|  Green / Stop |  Stop / Hold |

| Original | Replacement |
|---|---|
|  Green / Stop |  Green / APP / Repeat |
|  Yellow / Play |  Play / Slow |
|  Yellow / Play |  Yellow / YouTube / Repeat |
|  Blue / >>> |  >>> / Tune+ |
|  Blue / >>> |  Blue / Prime Video / Random |
|  Up |  Up |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Down |  Down |
|  SFI |  D.Menu / Top |
|  Exit / Recall |  Back / Return |
|  Exit / Recall |  Exit / Cancel / Clear |
|  Info |  Info / Angle |
|  Prog + |  CH+ / Page+ |
|  TV / Radio |  TV/Radio / |
|  Vol + |  Vol+ |





| Original | Replacement |
|-----------|-----------------------|
| Prog - | CH- / Page- |
| Menu | Menu / Home |
| Vol - | Vol- |
| TV/SAT | Smart / List |
| TXT | Text / Goto |
| Stop | Pause / Step / Freeze |
| EXT | Display / Media |
| SAT1 + OK | Shift + 2 |
| SAT2 + OK | Shift + 3 |
| TV + OK | Shift + 1 |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Replacement |
|----------|-------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

