
















Original	Replacement	Original	Replacement
	Power		Power
	SAT		AV
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Texts		Smart
	Back		Back
	Vol +		Vol +
	Vol -		Vol -

Original	Replacement	Original	Replacement
	Menu		Menu
	Exit		Exit
	Guide		Guide
	CH +		Ch +
	CH -		Ch -
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Page Down		Shift + Ch -
	Page Up		Shift + Ch +
	Info		Info
	Subtitle		Subt
	Audio		Dual
	Check		Shift + Ok
	Red		Red





Original	Replacement
Green	Green
Yellow	Yellow
Blue	Blue
Res	Format
Sleep	Sleep
TV / Radio	TV/R
Text	Text
Play	Play
Stop	Stop
Pause	Pause
Rec	Rec
Repeat	Shift + Text
Step	Shift + Pause
<<	<<
>>	>>
Picture	Shift + Format
Play Text	Shift + Play

Original	Replacement
I<<	I<<
>>I	>>I
List	List
Zoom	Eject
Mark	Pre Ch

