



















































Original	Replacement	Original	Replacement
Power	 Power	0	0
TV Set Power	 +  Shift + Power	Recall	 Back
TV Set V +	 Vol +	Audio	 Dual
TV Set V -	 Vol -	Menu	 Menu
Mute	 Mute	Exit	 Exit
TV Mode	 Options	Up	 Up
TV / Rad	 TV/R	Right	 Right
Find	 Media	Down	 Down
1	 1	Left	 Left
2	 2	OK	 Ok
3	 3	Sat	 AV
4	 4	Fav	 Pre Ch
5	 5	PG +	 Ch +
6	 6	PG -	 Ch -
7	 7	YouTube	 Smart
8	 8	Play / PauInfo	 Info
9	 9	EPG	 Guide



















Original	Replacement	Original	Replacement
Power	 Power	0	0
TV Set Power	 +  Shift + Power	Recall	 Back
TV Set V +	 Vol +	Audio	 Dual
TV Set V -	 Vol -	Menu	 Menu
Mute	 Mute	Exit	 Exit
TV Mode	 Options	Up	 Up
TV / Rad	 TV/R	Right	 Right
Find	 Media	Down	 Down
1	 1	Left	 Left
2	 2	OK	 Ok
3	 3	Sat	 AV
4	 4	Fav	 Pre Ch
5	 5	PG +	 Ch +
6	 6	PG -	 Ch -
7	 7	YouTube	 Smart
8	 8	Play / PauInfo	 Info
9	 9	EPG	 Guide












Original	Replacement	Original	Replacement
Play / Pause	 Play		
Play / Pause	 Pause		
<< FB	 <<		
>> FF	 >>		
Stop	 Stop		
I<< Prev	 I<<		
>>I Next	 >>I		
Sleep	 Sleep		
Sub-T	 Subt		
Text	 Text		
Rec	 Rec		
Red / IPTV	 Red		
Green / Video	 Green		
Yellow / PVR	 Yellow		
Blue / Timer	 Blue		



Original	Replacement	Original	Replacement
Power		Power	
Mute		Mute	
Menu		Menu	
Exit		Exit	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
SAT		AV	
TV Mode		Smart	
S.Mode	 + 	Shift + Dual	

Original	Replacement	Original	Replacement
Text		Text	
PG+		Ch +	
PG-		Ch -	
Up		Up	
Left		Left	
OK		Ok	
Right		Right	
Down		Down	
Recall		Back	
Sleep		Sleep	
Find	 + 	Shift + TV/R	
TV / Rad		TV/R	
Info		Info	
EPG		Guide	
FAV		Pre Ch	
YouTube		Media	
Red / M/P		Red	



Original	Replacement	Original	Replacement
Green / Video	 Green		
Yellow / PVR	 Yellow		
Blue / Timer	 Blue		
Audio	 Dual		
Subtitle	 Subt		
Stop	 Stop		
Rec	 Rec		
Play/Pause	 Play		
Play/Pause	 Pause		

