


































































































Original	Replacement	Original	Replacement
 Power	 Power	 Exit	 Exit
 [=i]/Info	 Info	 ♪	 Shift + Dual
 Mute	 Mute	 Enter	 Ok
 1	 1	 Up	 Up
 2	 2	 Down	 Down
 3	 3	 Right	 Right
 4	 4	 Left	 Left
 5	 5	 CH+	 Ch +
 6	 6	 CH-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 [=♦]/[+]	 Format
 0	 0	 List	 List
 [=?]/Source	 AV	 EPG	 Guide
 O)/II/Audio	 Dual	 Recall	 Pre Ch
 *	 Options	 [=]	 Text
 Menu	 Menu	 Play	 Play





Original	Replacement	Original	Replacement
 Pause	 Pause		
 [≡+]/Still	 3D		
 Stop	 Stop		
 [≡o]/Subtitle	 Subt		
 Radio	 TV/R		
 Sleep	 Sleep		
 FAV-	 Shift + Ch -		
 FAV+	 Shift + Ch +		
 Red	 Red		
 <<	 <<		
 Green	 Green		
 >>	 >>		
 I<<	 I<<		
 Yellow	 Yellow		
 Blue	 Blue		
 >>I	 >>I		
 [≡x]/Repeat	 D. Menu		

