









































































































| Original | Replacement | Original | Replacement |
|--|--|--|---|
|  Power |  Power |  Vol- |  Vol- |
|  Source |  AV / Input / RDS |  Vol+ |  Vol+ |
|  P.Mode |  Setup / OPT / |  Mute |  Mute / Dimmer |
|  S.Mode |  Sound / Title |  P+ |  CH+ / Page+ |
|  Home |  Shift + Menu / |  I/II/Audio |  Audio / Lang I/II |
|  1 |  1 |  P- |  CH- / Page- |
|  2 |  2 |  Subtitle |  Subtitle / EQ |
|  3 |  3 |  3D World |  Display / Media |
|  4 |  4 |  Info |  Info / Angle |
|  5 |  5 |  FAV |  Fav / Marker / PC |
|  6 |  6 |  Screen |  Picture / Format |
|  7 |  7 |  CH List |  Smart / List |
|  8 |  8 |  Menu |  Menu / Home |
|  9 |  9 |  Up |  Up |
|  Q.View |  D.Menu / Top |  Guide |  Guide / EPG / -/- |
|  0 |  0 |  Left |  Left |
|  Sleep |  Sleep / Timer |  OK |  OK |





| Original | Replacement | Original | Replacement |
|---|-------------|---|-----------------------------|
|  | Right |  | Right |
|  | Back |  | Back / Return |
|  | Down |  | Down |
|  | Exit |  | Exit / Cancel / Clear |
|  | Red |  | Red / Netflix / Search |
|  | << |  | << / Tune- |
|  | Green |  | Green / APP / Repeat |
|  | >> |  | >> / Tune+ |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | l<< |  | l<< / Preset- |
|  | Blue |  | Blue / Prime Video / Random |
|  | >>l |  | >>l / Preset+ |
|  | Text |  | Text / Goto |
|  | Play |  | Play / Slow |
|  | Pause |  | Pause / Step / Freeze |
|  | Stop |  | Stop / Hold |
|  | Rec |  | Rec / Rec Mode |

