





Original	Replacement	Original	Replacement
 Power	 Power	 5	 5
 Mute	 Mute	 6	 6
 DTV / Radio	 TV/R	 7	 7
 AVC	 Smart	 8	 8
 Info	 Info	 9	 9
 TV Audio	 Dual	 0	 0
 DTV / TV	 Shift + TV/R	 Recall	 Back
 Sleep	 Sleep	 Vol+	 Vol +
 Wide	 Format	 Vol-	 Vol -
 Subtitle	 Subt	 Guide	 Guide
 Freeze	 Pause	 List	 List
 Picture	 Shift + Format	 Prog+	 Ch +
 Sound	 Shift + Dual	 Prog-	 Ch -
 1	 1	 Exit	 Exit
 2	 2	 Favorite	 Pre Ch
 3	 3	 Up	 Up
 4	 4	 Left	 Left





Original		Replacement		Original		Replacement	
	OK		Ok				
	Right		Right				
	Down		Down				
	Input		AV				
	Menu		Menu				
	TXT Hold		Stop				
	TXT Update		Shift + Exit				
	TXT Subcode		Shift + Subt				
	Text / Mix		Text				
	TXT Index		Options				
	TXT List		Shift + List				
	TXT Size		Eject				
	TXT Reveal		Media				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

