











































































Original	Replacement	Original	Replacement
 Power	 Power	 YouTube	 Shift + Media
 Mute	 Mute	 Back	 Back
 1	 1	 Home	 Smart
 2	 2	 Exit	 Exit
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 OK	 Ok
 8	 8	 Red	 Red
 9	 9	 Green	 Green
 0	 0	 Yellow	 Yellow
 List	 List	 Blue	 Blue
 AD	 Shift + Subt	 [+]	 3D
 Source	 AV	 Info	 Info
 prime video	 Shift + Smart	 Vol+	 Vol +
 Netflix	 Media	 Vol-	 Vol -

Original	Replacement	Original	Replacement
 MUTE	 MUTE	 TV	 DVD
 MUTE	 MUTE	 SAT	 AUX
 SHIFT	 SHIFT	 PLAY MODE	 REC MODE
 TV	 DVD	 Play	 Pause
 DVD	 SAT	 Stop	 FF
 SAT	 AUX	 RR	 Play
 AUX	 MUTE	 Home	 MUTE
 MUTE	 SHIFT	 Back	 SHIFT
 SHIFT	 MUTE	 Exit	 MUTE
 MUTE	 SHIFT	 Up	 SHIFT
 SHIFT	 MUTE	 Down	 MUTE
 MUTE	 SHIFT	 Right	 SHIFT
 SHIFT	 MUTE	 Left	 MUTE
 MUTE	 SHIFT	 OK	 SHIFT
 SHIFT	 MUTE	 Red	 MUTE
 MUTE	 SHIFT	 Green	 SHIFT
 SHIFT	 MUTE	 Yellow	 MUTE
 MUTE	 SHIFT	 Blue	 SHIFT
 SHIFT	 MUTE	 Home	 MUTE
 MUTE	 SHIFT	 SMART	 SHIFT
 SHIFT	 MUTE	 APP MEDIA	 MUTE
 MUTE	 SHIFT	 VOL +	 SHIFT
 SHIFT	 MUTE	 VOL -	 MUTE
 MUTE	 SHIFT	 CH +	 SHIFT
 SHIFT	 MUTE	CH -	 MUTE





Original		Replacement		Original	Replacement
	CH+		Ch +		
	CH-		Ch -		
	EPG		Guide		
	Audio		Dual		
	Subtitle		Subt		
	TTX		Text		
	<<		<<		
	>>		>>		
	Rec		Rec		
	Play		Play		
	Pause/T.Shift		Pause		
	Stop/Rec List		Stop		

