




































































Original	Replacement	Original	Replacement
 OP/CL	 Eject / Surround	 Angle	 Info / Angle
 Source	 AV / Input / RDS	 Audio	 Audio / Lang I/II
 Power	 Power	 Menu	 Menu / Home
 1	 1	 Up / CH+	 Up
 2	 2	 Up / CH+	 CH+ / Page+
 3	 3	 Setup	 Setup / OPT /
 4	 4	 Left	 Left
 5	 5	 Enter	 OK
 6	 6	 Right	 Right
 7	 7	 Rev	 << / Tune-
 8	 8	 Down / CH-	 Down
 9	 9	 Down / CH-	 CH- / Page-
 0	 0	 Next	 >>I / Preset+
 10+	 Guide / EPG / -/-	 Fwd	 >> / Tune+
 Auto Scan	 Sleep / Timer	 Prev	 I<< / Preset-
 Title / Text	 Sound / Title	 Vol-	 Vol-
 Subtitle	 Subtitle / EQ	 Play/Pause	 Play / Slow





Original	Replacement	Original	Replacement
 Play/Pause	 Pause / Step / Freeze	 Prog / EPG	 Shift + Guide / EPG / -/--
 Vol+	 Vol+	 V.Mode	 Shift + 4
 Stop	 Stop / Hold	 V.Mode	 Picture / Format
 Resume	 Rec / Rec Mode	 Step	 Shift + Pause / Step /
 Zoom	 Zoom / Size	 A-B	 Shift + Yellow / YouTube /
 Mute	 Mute / Dimmer		
 Red / Clear	 Exit / Cancel / Clear		
 Red / Clear	 Red / Netflix / Search		
 Green / Ran	 Green / APP / Repeat		
 Yellow / PBC	 Yellow / YouTube / Repeat		
 Blue / Repeat	 Shift + Green / APP /		
 Blue / Repeat	 Blue / Prime Video / Random		
 OSD	 Display / Media		
 N/P	 Text / Goto		
 Slow	 Shift + Play /		
 Return	 Back / Return		
 Prog / EPG	 TV/Radio /		



Program