














































Original	Replacement	Original	Replacement
 Standby	 Power	 -/--	 Shift + Guide
 Mute	 Mute	 Recall	 Pre Ch
 Source	 AV	 Menu	 Menu
 P.Mode	 Shift + Format	 Exit	 Exit
 S.Mode	 Shift + Dual	 Text	 Text
 Audio I/II	 Dual	 Display	 Info
 Sleep	 Sleep	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 CH+	 Ch +
 8	 8	 CH-	 Ch -
 9	 9	 Red	 Red
 0	 0	 Green	 Green





Original	Replacement	Original	Replacement
	Yellow		Yellow
	Blue		Blue
	Subtitle		Subt
	Size		Format
	Reveal		Back
	Mix		Smart
	Index		List
	EPG		Guide
	Play		Play
	Pause/Hold		Pause
	Stop/FAV		Stop
	I<</Cancel		I<<
	>>I/Subpage		>>I
	<</FAV-		<<
	>>/FAV+		>>

