



| Original | Replacement | Original | Replacement |
|--|---|--|---|
|  Power |  Power |  Right |  Right |
|  1 |  1 |  Left |  Left |
|  2 |  2 |  Enter |  Ok |
|  3 |  3 |  << |  << |
|  4 |  4 |  >> |  >> |
|  5 |  5 |  I<< |  I<< |
|  6 |  6 |  Stop |  Stop |
|  7 |  7 |  >>I |  >>I |
|  8 |  8 |  Play |  Play |
|  9 |  9 |  Pause |  Pause |
|  0 |  0 |  Step |  Sleep |
|  Open/Close |  Eject |  Audio |  Dual |
|  Title Menu |  D. Menu |  Subpic |  Subt |
|  Menu |  Menu |  Angle |  Smart |
|  Back |  Back |  Zoom |  Shift + Eject |
|  Up |  Up |  Repeat |  Text |
|  Down |  Down |  Mark |  Media |



