







































































Original	Replacement	Original	Replacement
 Power	 Power	 Vol+	 Vol+
 e/Energy/Savin	 Sleep / Timer	 FAV/Mark	 Fav / Marker / PC
 AV Mode	 Eject / Surround	 P+	 CH+ / Page+
 Input	 AV / Input / RDS	 Vol-	 Vol-
 TV/RAD	 TV/Radio /	 Ratio	 Picture / Format
 1	 1	 P-	 CH- / Page-
 2	 2	 Mute	 Mute / Dimmer
 3	 3	 Menu	 Menu / Home
 4	 4	 Guide	 Guide / EPG / -/-
 5	 5	 Q.Menu	 D.Menu / Top
 6	 6	 Up	 Up
 7	 7	 Left	 Left
 8	 8	 OK	 OK
 9	 9	 Right	 Right
 List	 Smart / List	 Down	 Down
 0	 0	 Back	 Back / Return
 Q.View	 Display / Media	 Info	 Info / Angle





Original		Replacement		Original	Replacement
	Exit		Exit / Cancel / Clear		
	Red		Red / Netflix / Search		
	Green		Green / APP / Repeat		
	Yellow		Yellow / YouTube / Repeat		
	Blue		Blue / Prime Video / Random		
	Text		Text / Goto		
	T.Opt		Setup / OPT /		
	Subtitle		Subtitle / EQ		
	Stop		Stop / Hold		
	Play		Play / Slow		
	Pause		Pause / Step / Freeze		
	<<		<< / Tune-		
	>>		>> / Tune+		
	Simplink		Zoom / Size		
	AD		Audio / Lang I/II		

