



Original	Replacement	Original	Replacement
 Power	 Power	 Ratio/Char/Num	 Dual
 Energy/Saving	 3D	 Q.View	 D. Menu
 AV Mode	 Shift + AV	 Vol+	 Vol +
 Input	 AV	 Vol-	 Vol -
 Tv/Radio	 TV/R	 Mute/Delete	 Mute
 1	 1	 P+	 Ch +
 2	 2	 P-	 Ch -
 3	 3	 Premium	 Media
 4	 4	 Home Netcast	 Smart
 5	 5	 Q.Menu	 Menu
 6	 6	 Back	 Back
 7	 7	 Guide	 Guide
 8	 8	 Exit	 Exit
 9	 9	 Up	 Up
 0	 0	 Down	 Down
 List	 List	 Right	 Right
 FAV/Mark	 Pre Ch	 Left	 Left





Original		Replacement		Original		Replacement	
	OK		Ok				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Text		Text				
	Subtitle		Subt				
	T.Opt		Options				
	Simplink		Format				
	Info		Info				
	AD		Shift + Subt				
	Stop		Stop				
	Play		Play				
	Pause		Pause				
	<<		<<				
	>>		>>				

