





































| Original                                                                                        | Replacement                                                                                                   |
|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
|  Power         |  Power                       |
|  Red/Demo      |  Red / Netflix / Search      |
|  Green         |  Green / APP / Repeat        |
|  Yellow        |  Yellow / YouTube / Repeat   |
|  Blue          |  Blue / Prime Video / Random |
|  Option        |  Setup / OPT /               |
|  [ I ]         |  Info / Angle                |
|  Up            |  Up                          |
|  Left          |  Left                        |
|  OK            |  OK                          |
|  Right         |  Right                       |
|  Down         |  Down                       |
|  Menu/Browse |  Menu / Home               |
|  [ ≡ ]       |  Text / Goto               |
|  Vol+        |  Vol+                      |
|  P+          |  CH+ / Page+               |
|  Vol-        |  Vol-                      |

| Original                                                                                        | Replacement                                                                                           |
|-------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|
|  Mute        |  Mute / Dimmer     |
|  P-          |  CH- / Page-       |
|  1           |  1                 |
|  2           |  2                 |
|  3           |  3                 |
|  4           |  4                 |
|  5           |  5                 |
|  6           |  6                 |
|  7           |  7                 |
|  8           |  8                 |
|  9           |  9                 |
|  AV         |  AV / Input / RDS |
|  0         |  0               |
|  P<P       |  Back / Return   |
|  Ambilight |  Smart / List    |
|  Mode      |  D.Menu / Top    |
|  <<        |  << / Tune-      |



