



Original	Replacement
 Power	 Power
 Input	 AV
 VF	 Smart
 AR	 Shift + Smart
 SAT	 Media
 TV / Radio	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Menu	 Menu

Original	Replacement
 Exit	 Exit
 FAV	 Pre Ch
 Text	 Text
 Mute	 Mute
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Back	 Back
 V +	 Vol +
 V -	 Vol -
 APP	 Shift + Media





Original		Replacement		Original		Replacement	
	EPG		Guide				
	P +		Ch +				
	P -		Ch -				
	Audio		Dual				
	Sub		Subt				
	List		List				
	Info		Info				

