







































































Original	Replacement
 TV	 TV/R
 Video	 Smart
 PC	 Media
 Text	 Text
 P+	 Ch +
 Up	 Up
 P-	 Ch -
 Down	 Down
 Right	 Right
 Vol+	 Vol +
 Left	 Left
 Vol-	 Vol -
 Menu	 Menu
 Menu	 Ok
 Mute	 Mute
 Red / M	 Red
 Green	 Green

Original	Replacement
 Yellow	 Yellow
 Blue	 Blue
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/-	 Guide
 L / ?	 List
 Freeze	 Pause
 M/S	 Options
 PIP	 3D





Original	Replacement
 Auto	 Back
 F[+]	 Format
 i	 Info
 F1	 Shift + 1
 Clock	 AV
 F2	 Shift + 2
 F3	 Shift + 3
 F4	 Shift + 4
 Power	 Power

Original	Replacement

