





































































Original	Replacement	Original	Replacement
 Power	 Power	 Menu	 Menu
 Mute	 Mute	 A.Swap	 Back
 1	 1	 Input	 AV
 2	 2	 Text	 Text
 3	 3	 Q.View	 Options
 4	 4	 Sleep	 Sleep
 5	 5	 Exit	 Exit
 6	 6	 Up / PR+	 Up
 7	 7	 Up / PR+	 Ch +
 8	 8	 Left / Vol-	 Vol -
 9	 9	 Left / Vol-	 Left
 0	 0	 OK	 Ok
 PSM	 Format	 Right / Vol+	 Right
 SSM	 Shift + Dual	 Right / Vol+	 Vol +
 List	 List	 Down / PR-	 Ch -
 ARC	 3D	 Down / PR-	 Down
 I/II	 Dual	 Red / PIP PR+	 Red



