







































































| Original | Replacement | Original | Replacement |
|---|--|--|---|
|  Standby |  Power |  Tv/Radio |  TV/R |
|  Source |  AV |  Display |  Info |
|  1 |  1 |  Menu |  Menu |
|  2 |  2 |  Exit |  Exit |
|  3 |  3 |  Up |  Up |
|  4 |  4 |  Down |  Down |
|  5 |  5 |  Right |  Right |
|  6 |  6 |  Left |  Left |
|  7 |  7 |  OK |  Ok |
|  8 |  8 |  Vol+ |  Vol + |
|  9 |  9 |  Vol- |  Vol - |
|  0/10 |  0 |  Mute |  Mute |
|  FAV/Program |  Pre Ch |  EPG |  Guide |
|  Recall/10+ |  Back |  Media |  Media |
|  P.Mode |  Format |  CH+ |  Ch + |
|  S.Mode |  Shift + Dual |  CH- |  Ch - |
|  Sleep |  Sleep |  Rec |  Rec |





| Original | | Replacement | | Original | | Replacement | |
|---|-------------|---|---------------|---|--------------|---|--------|
|  | T.Shift |  | Smart |  | Green/A-B |  | Green |
|  | I/II/Audio |  | Dual |  | Yellow/Angle |  | Yellow |
|  | Size/Aspect |  | 3D |  | Blue/Repeat |  | Blue |
|  | D.Setup |  | Options | | | | |
|  | D.Menu |  | D. Menu | | | | |
|  | Title |  | Text | | | | |
|  | Eject |  | Eject | | | | |
|  | Play |  | Play | | | | |
|  | Pause/Hold |  | Pause | | | | |
|  | Stop/Reveal |  | Stop | | | | |
|  | <</Text |  | << | | | | |
|  | >>/Subpage |  | >> | | | | |
|  | I<</Index |  | I<< | | | | |
|  | >>I/Mix |  | >>I | | | | |
|  | Zoom |  | Shift + Eject | | | | |
|  | Subtitle |  | Subt | | | | |
|  | Red/Goto |  | Red | | | | |

