



Original	Replacement	Original	Replacement
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Mute		Mute
	Subtl		Subt
	Vol+		Vol +
	Vol-		Vol -
	-ISI-		Shift + Dual
	-IPI-		Shift + Format
	P+		Ch +
	P-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK/Select		Ok
	DTV Menu		D. Menu
	Call		Pre Ch
	ATV Menu		Menu
	Sleep		Sleep
	Exit		Exit
	I/II		Dual
	QV		3D
	EPG		Guide
	Page+		>>





Original	Replacement	Original	Replacement
 Page-	 <<		
 Info	 Info		
 Text	 Text		
 Mix	 TV/R		
 [II]/Size	 Format		
 Index	 List		
 Hold	 Media		
 Reveal	 Options		
 Cancel	 Back		
 Subpage	 Eject		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

