





Original	Replacement	Original	Replacement
	Power		Power
	Input		AV
	TV/TXT		Text
	Cancel		Eject
	Reveal		Media
	Nicam/A2		Dual
	Hold		Options
	Size		Format
	Subpage		D. Menu
	Index		Smart
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	CH+		Ch +
	CH-		Ch -
	Menu		Menu
	Exit		Exit
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Channel List		TV/R
	EPG		Guide
	Info		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	1		1
	2		2
	3		3
	4		4
	5		5





Original	Replacement
6	6
7	7
8	8
9	9
0	0
FAV	Pre Ch
Picture	Shift + Format
Sound	Shift + Dual
Recall	Back
Sleep	Sleep
Subtitle	Subt
Aspect	3D
Rec	Rec
<<	<<
>>	>>
List	List
I<<	I<<

Original	Replacement
>>I	>>I
Repeat	Shift + Text
Play	Play
Pause	Pause
Stop	Stop

