











































































































| Original | Replacement | Original | Replacement |
|---|---------------|---|-----------------------------|
|  | Power |  | Power |
|  | Mute |  | Mute / Dimmer |
|  | Aspect |  | Shift + Picture / Format |
|  | P.Mode |  | Picture / Format |
|  | S.Mode |  | Sound / Title |
|  | Audio / Nicam |  | Audio / Lang I/II |
|  | Sleep |  | Sleep / Timer |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | -/-- |  | Shift + Guide / EPG / -/-- |
|  | Recall |  | Back / Return |
|  | Red |  | Red / Netflix / Search |
|  | Green |  | Green / APP / Repeat |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | Blue |  | Blue / Prime Video / Random |
|  | Source |  | AV / Input / RDS |
|  | Up |  | Up |
|  | Menu |  | Menu / Home |
|  | Left |  | Left |
|  | Enter |  | OK |
|  | Right |  | Right |
|  | Down |  | Down |
|  | Vol + |  | Vol+ |
|  | Exit |  | Exit / Cancel / Clear |
|  | CH + |  | CH+ / Page+ |
|  | Vol - |  | Vol- |





| Original | Replacement |
|---|--|
|  Display |  Display / Media |
|  CH - |  CH- / Page- |
|  TXT |  Text / Goto |
|  Index |  Setup / OPT / |
|  Hold |  Shift + Stop / |
|  Mix |  Shift + Text / |
|  Subpage |  Eject / Surround |
|  Reveal / Subtitle |  Subtitle / EQ |
|  Size |  Zoom / Size |
|  Rec / Goto / |  Rec / Rec Mode |
|  EPG |  Guide / EPG / -/-- |
|  List |  Smart / List |
|  TV / Radio |  TV/Radio / |
|  FAV |  Fav / Marker / PC |
|  Play / Pause |  Play / Slow |
|  Play / Pause |  Shift + Play / |
|  Stop |  Stop / Hold |

| Original | Replacement |
|--|---|
|  PVR Menu |  D.Menu / Top |
|  Media |  Shift + Display / Media |
|  I<< |  I<< / Preset- |
|  >>I |  >>I / Preset+ |
|  << |  << / Tune- |
|  >> |  >> / Tune+ |

