





































































































Original		Replacement		Original		Replacement	
	Power		Power		OK		Ok
	3D		3D		Option		Options
	Tv Input		TV/R		Return/Back		Back
	AV Input		AV		Red		Red
	Menu		Menu		Green		Green
	[≡]/Text		Text		Yellow		Yellow
	[≡♦]/STTL		Subt		Blue		Blue
	[+]/Aspect		D. Menu		Vol+		Vol +
	X/Exit		Exit		Vol-		Vol -
	i		Info		Mute		Mute
	APPS		Format		PR+		Ch +
	Home		Smart		PR-		Ch -
	Guide		Guide		1		1
	Up		Up		2		2
	Down		Down		3		3
	Right		Right		4		4
	Left		Left		5		5





Original		Replacement		Original		Replacement	
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	?/Help		Dual				
	Last View		Pre Ch				
	<<		<<				
	Play		Play				
	>>		>>				
	I<<		I<<				
	Pause		Pause				
	>>I		>>I				
	Stop		Stop				
	Rec		Rec				

