









































Original	Replacement
 Power	 Power
 Power AV	 Shift + Power
 Sleep	 Sleep
 TV/AV	 AV
 Band/Tuner	 TV/R
 Double Re-Master	 Smart
 Group	 3D
 Repeat/MIX 2CH	 Text
 Play Mode / P.Memory	 Shift + Play
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8

Original	Replacement
 9	 9
 0	 0
 -/_/+10	 Guide
 Cancel	 Exit
 I<< Skip	 I<<
 Skip >>I	 >>I
 <<	 <<
 Scan/Saerch	 >>
 Stop	 Stop
 Pause	 Pause
 Play	 Play
 Top Menu / Direct Navigator	 Shift + Menu
 Top Menu / Direct Navigator	 D. Menu
 Menu / Play List	 Menu
 Menu / Play List	 List
 Up	 Up
 Left	 Left





Original	Replacement
 Enter	 Ok
 Right	 Right
 Down	 Down
 Display	 Info
 Return	 Back
 Vol-	 Vol -
 Vol+	 Vol +
 Muting	 Mute
 C.S.M.	 Red
 Dolby/PL II	 Subt
 Subwoofer	 Format
 RDS / Fl.Display	 Blue
 Audio Only	 Dual
 C.Focus	 Rec
 S.F.C.	 Green
 Setup / FM	 Options
 CH Select	 Ch +

Original	Replacement
 Test	 Yellow
 Delay Time	 Ch -













Original	Replacement
 Power	 Power
 Power AV	 +  Shift + Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/-/+10	 Guide
 CH+	 Ch +
 CH-	 Ch -
 Tv Vol+	 Vol +
 Tv Vol-	 Vol -

Original	Replacement





Original	Replacement
 Power	 Power
 Power AV	 Shift + Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 $\geq 10/-/+$	 GUIDE Guide
 I<</CH-	 I<< I<<
 >>I/CH+	 >>I >>I
 << Slow/Search	 << <<
 /SEARCH Slow/Saerch >>	 >> >>

Original	Replacement
 Stop	 Stop
 Pause	 Pause
 Play	 Play
 Display	 Info

