







Original	Replacement
 Power	 Power
 Input	 AV / Input / RDS
 Menu	 Menu / Home
 Picture	 Picture / Format
 Text	 Text / Goto
 STTL	 Subtitle / EQ
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 i	 Info / Angle
 Exit	 Exit / Cancel / Clear
 Netflix	 Shift + Red / Netflix / Search
 prime video	 Shift + Blue / Prime / Random
 Up	 Up
 YouTube	 Shift + Yellow / YouTube / Repeat A-B
 Left	 Left

Original	Replacement
 OK	 OK
 Right	 Right
 Back	 Back / Return
 Down	 Down
 Home	 Shift + Menu / Home
 Mute	 Mute / Dimmer
 Sound	 Sound / Title
 Guide	 Guide / EPG / -/-
 List	 Shift + Smart / List
 Vol+	 Vol+
 P+	 CH+ / Page+
 Vol-	 Vol-
 Smart	 Smart / List
 P-	 CH- / Page-
 1	 1
 2	 2
 3	 3



