







































































Original	Replacement	Original	Replacement
	Power		Power
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Rec		Rec / Rec Mode
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Tv Guide		Guide / EPG / -/-
	Setup		Setup / OPT /
	Format		Picture / Format
	Sources		AV / Input / RDS
	Exit		Exit / Cancel / Clear
	Home		Menu / Home
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Info		Info / Angle
	Options		Shift + Setup / OPT / Tools
	Back		Back / Return
	List		Smart / List
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Ok		Ok
	Vol+		Vol+
	Vol-		Vol-
	Mute		Mute / Dimmer
	CH+		CH+ / Page+
	CH-		CH- / Page-
	1		1
	2		2
	3		3





Original		Replacement	
<b>4</b> GHI	4	<b>4</b> VIDEO	4
<b>5</b> JKL	5	<b>5</b> TAPE	5
<b>MNO 6</b>	6	<b>6</b> TUNER	6
<b>7</b> PQRS	7	<b>7</b> AUX - HDD	7
<b>8</b> TUV	8	<b>8</b> USB	8
<b>WXYZ 9</b>	9	<b>9</b> BLUETOOTH	9
<b>0</b>	0	<b>0</b> HDMI - SAT	0
<b>SUBTITLE</b>	Subtitle	<b>SUBTITLE</b> EQ	Subtitle / EQ
<b>TEXT</b>	Text	<b>TEXT</b> GOTO	Text / Goto

Original		Replacement	

