





































Original	Replacement
 Power	 Power
 Red/Demo	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Option	 Setup / OPT /
 [I]	 Guide / EPG / -/--
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Menu/Browse	 Menu / Home
 [≡]	 Text / Goto
 Vol+	 Vol+
 P+	 CH+ / Page+
 Vol-	 Vol-

Original	Replacement
 Mute	 Mute / Dimmer
 P-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 AV	 AV / Input / RDS
 0	 0
 P<P	 Back / Return
 <<	 << / Tune-
 Stop/Cancel	 Exit / Cancel / Clear
 Stop/Cancel	 Stop / Hold





Original	Replacement	Original	Replacement
	Play		Play / Slow
	>>		>> / Tune+
	Rec		Rec / Rec Mode
	[i+]		Info / Angle
	[12]		Display / Media
	FAV		Fav / Marker / PC





Original	Replacement
	Power
	Up
	Left
	OK
	Right
	Down
	Menu / Home
	CH+ / Page+
	CH- / Page-
	1
	2
	3
	4
	5
	6
	7
	8

Original	Replacement
	9
	0
	Fav / Marker / PC
	<< / Tune-
	Stop / Hold
	Play / Slow
	>> / Tune+
	Info / Angle
	Subtitle / EQ
	Back / Return
	Pause / Step / Freeze





Original	Replacement
 Power	 Power
 Red/Demo	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Guide	 Guide / EPG / -/--
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Menu	 Menu / Home
 Teletext	 Text / Goto
 P+	 CH+ / Page+
 P-	 CH- / Page-
 1	 1
 2	 2

Original	Replacement
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 P↔P	 Fav / Marker / PC
 <<	 << / Tune-
 CANCEL	 Stop / Hold
 Play	 Play / Slow
 >>	 >> / Tune+
 Rec	 Rec / Rec Mode
 Info	 Info / Angle
 [12]	 Zoom / Size
 Subtitle	 Subtitle / EQ





Original	Replacement	Original	Replacement
Back	 Back / Return		
Pause	 Pause / Step / Freeze		

