





































Original	Replacement	Original	Replacement
	Power		Power
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Pop Up Menu/Disc Menu		D. Menu
	Top Menu		Menu
	Home		Smart
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Back		Back
	≡/Options		Options
	Play		Play
	Pause		Pause

Original	Replacement	Original	Replacement
	Stop/Open/Clos		Stop
	Stop/Open/Clos		Eject
	>>		>>
	<<		<<
	>		>>
	<		<<
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Subtitle		Subt



[illegible]