



Original	Replacement	Original	Replacement
	Power		Power
	Stop		Stop
	Pause		Pause
	Rec		Rec
	<<		<<
	Play		Play
	>>		>>
	Source		AV
	TV		TV/R
	Guide		Guide
	Home		Smart
	List		List
	Info		Info
	Format		Format
	Options		Options
	Up		Up
	Down		Down

Original	Replacement	Original	Replacement
	Right		Right
	Left		Left
	Ok		Ok
	Back ←		Back
	CH+		Ch +
	CH-		Ch -
	Vol +		Vol +
	Vol -		Vol -
	Mute		Mute
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	1		1
	2		2
	3		3
	4		4



