



Original	Replacement
	Power
	Eject / Surround
	AV / Input / RDS
	Sleep / Timer
	Up
	>> / Tune+
	I << / Preset-
	Shift + I << / Preset-
	OK
	>> / Preset+
	Shift + >> / Preset+
	Down
	Stop / Hold
	Menu / Home
	Vol +
	Play / Slow
	Pause / Step / Freeze

Original	Replacement
	Vol -
	Shift + Dimmer / Mute
	Mute / Dimmer
	Green / APP / Repeat
	TV/Radio /
	Sound / Title
	Shift + Sleep / Timer
	Subtitle / EQ

