




















































































Original	Replacement	Original	Replacement
 Power Blue	 Shift + Power	 >>	 >>
 POWER Red	 Power	 Home	 Smart
 RED / F1	 Red	 BACK	 Back
 GREEN / F2	 Green	 UP	 Up
 YELLOW / F3	 Yellow	 LEFT	 Left
 BLUE / F4	 Blue	 OK	 Ok
 MUTE	 Mute	 RIGHT	 Right
 AV	 AV	 DOWN	 Down
 Sound Mode	 Dual	 : ≡	 Menu
 SETUP	 Options	 i	 Info
 APP	 Media	 VOL+	 Vol +
 TV	 TV/R	 PLAY/PAUSE	 Pause
 ≡	 Text	 PLAY/PAUSE	 Play
 KB	 Guide	 CHAN.+	 Ch +
 I<<	 I<<	 VOL-	 Vol -
 >>I	 >>I	 STOP	 Stop
 <<	 <<	 CHAN.-	 Ch -





	Original	Replacement		Original	Replacement
	1		1		
	2		2		
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		
	8		8		
	9		9		
	Format		Format		
	0		0		
	Recall		Pre Ch		

